


# *Basic Directions*

## **1. Turn on unit:**

Hold  button for about 3 seconds, unit starts heating and LCD blinks until setting temperature reached. It will take about 3 minutes. (Default temperature setting: 380°F)



## **2. Temperature adjust:**

Press "+" or "-" button to desired temperature.

Press "+" or "-" button one time, the temperature setting will increase or decrease 10°F

Temperature range: 340°F-410°F

LCD will keep blinking until setting temperature is reached.

Once you adjust temperature setting level it will take about 3 minutes.

## *Basic Directions (cont.)*

### 3. Lock function:


Press  button twice within 3 seconds, temperature adjust function will be locked.  
A lock mark will appear on the LCD (Fig 1)



Fig 1



Press  button twice within 3 seconds again, temperature adjust function will be unlocked. Lock mark will disappear from the LCD (Fig 2)



Fig 2

### 4. Shut off:

Hold  button for about 3 seconds, unit will be shut off.

5. Unit will shut off automatically after 1 hour.