



1. Protective Cover
2. Micro-Pedi Roller
 - blue for regular skin
3. End Cap of Micro-Pedi Roller
4. Safety Switch Lock
5. On/Off switch
6. Release Button for Micro-Pedi Roller
7. Battery cover (bottom cap of handle)

