

CLEANING

The **Emjoi® Micro-Pedi** is water resistant. It can be rinsed under water for cleaning but it is not water proof. Do not submerge the unit into water on purpose as this may cause defects to the unit. **Micro-Pedi rollers should not be placed into water.**

1. Turn the unit off.
2. Remove the protective cover and the Micro-Pedi roller from the unit.
Note: Micro-Pedi rollers should not be placed into water.
3. Rinse the unit under the tap for 5-8 seconds. Wipe the body of the unit with a clean dry cloth.
4. Replace the protective cover.