




Kringle Express Holographic RGB Characters



- 1) Assemble outdoor adaptor with 9ft cord by connecting the cord plug into the electric adapter as shown.
- 2) Tighten the twist-on connector by hand to secure the cord plug into place with the electric adapter.
- 3) To operate, insert electric adapter into electrical outlet.

Character can be operated by controller on lead wire, Remote or App
Controller Key Instruction - Located on Leadwire



- 1) when it's power off:
short press to turn on the device
- 2) when it's power on:
short press to change the dynamic mode
- 3) long press for 5 Seconds to turn off the device

How to connect to your phone:

- Apple: in the mobile App store, search for "iDeal LED" and download onto your phone
- Android: download "iDeal LED" in the Google app market

①

(4) After installed APP can examine the APP by setting the operating instructions.



②

NOTE: Remote must be pointed at Controller on lead wire to function

③

Note:

- Do not place this product in water for use.
- Do not place the product near fire.
- If you do not use this product for a long time, disconnect from power supply and place it in a cool and dry place.
- Keep away from Children
- Please do not disassemble the product.
- Do not allow knots to occur or tighten on wire cord during use.
- Indoor/Outdoor safe
- Battery information – i.e. includes 1 CR2025 button cell battery

CE RoHS
 FCC ID: 2A5NB-HCL-001
 MADE IN CHINA

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



④

Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children.

Do NOT dispose of batteries in household trash or incinerate.

Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

Battery type CR2025.

Nominal battery voltage: 3V

Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above 122°F / 50°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and -).

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be practiced including the following:

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
2. Read and follow all instructions that are on the product or provided with the product.
3. Do not use an extension cord.

⑤

4. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
5. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
6. Do not install or use within 10 feet of a pool.
7. Do not use in a bathroom.
8. **WARNING: Risk of Electric Shock.** When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
9. **WARNING: Risk of Fire.** Installation involves special wiring methods to run wiring through a building structure. Consult a qualified electrician.
10. For a unit intended to be mounted greater than 0.30 m (1 foot) from the ground surface: **WARNING: Risk of Electric Shock.** Mount the unit at a height greater than 1 foot from the ground surface.

SAVE THESE INSTRUCTIONS – This manual contains important safety and operating instructions for power units.


⑥

Model Number	HCL - 001
Trade Name	iDeal led
FCC Compliance Statement	
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	
Warning: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:	
—Reorient or relocate the receiving antenna.	
—Increase the separation between the equipment and receiver.	
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.	
—Consult the dealer or an experienced radio/TV technician for help.	
Responsible Party – U.S. Contact Information	
Company:	QVC USA
Address:	1200 Wilson Drive West Chester, PA 19380
Telephone or internet contact information:	888-345-5788

⑦

Ground Stakes:

Insert 1 ground stake into each side of your character into either the plastic tab or the metal frame depending on your choice of character.



⑧