



80019 MISTING FAN
Instructions


Congratulations on your purchase of SUNNEDAY Misting Fan.

This portable misting fan can provide both mist and fan capabilities. This unique fan can keep your face and skin moisturized in your home, office or outdoors. The misting fan can also cool you down on those hot days. This fan can refresh you instantly on those tired days.

Caution

- After use of the misting function, it is normal for the misting nozzle collect water droplets. This can affect the misting function. Simply wipe clean.
- If the fan doesn't mist immediately, please turn the fan upside down and gently shake. Air bubbles sometimes get in the tubing and that will stop the waterflow. A gentle shake usually will shift the air bubbles and fan will start misting again.
- When using the misting function, please always remember to have water in the water tank.
- It is always best to drain the water tank completely out of water if you are going to store the product or not use it for a while. This will prevent any type of buildup or bacteria.

- Please recharge the device if you feel the wind force and misting effect is not sufficient. When the battery gets low the fan speed slows slightly as well as the misting function. This unit can operate and function while being charged on a desktop.
- Do not add the alcohol, perfume or essential oils, this will cause the water tank to corrode.



Instructions for operation

1. Charge device for 2.5 Hours before first use.
2. The lower red LED's indicator will light when charging and turn off when charging is completed.
3. Fill water tank using tap or bottled water.
4. The fan has 3 different mode selections: Fan Mode /Misting Mode/Fan + misting. Press the top button to start three (3) speed fan. Press repeatedly to change the speed from Low, Middle to High level.

5. Press lower button to start continuous misting function. Press again for intermittent mist, the intermittent pattern is mist for 3 seconds and stop for 3 seconds and repeat.
6. The device will have a high frequency noise if there is a water shortage under the misting mode or fan+misting mode. Please turn the device off immediately and add the water to start misting again.
7. The misting function will automatically stop after 1 hour spraying even you forget to turn it off.

Specifications

Working Voltage: 5V 1A	Max Power: About 2.5W
Working Mode: 3levels speed	Atomization: 40ML/HR
Battery capacity: 2000mAh	Water Tank Capacity: 25mL
Working Time: About 2-6 Hours	Charging Time: About 2.5 Hours
Product weight: 175g	

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Sunneday LLC, Pawnee City, NE 68420, 1 (888) 254-2714

"Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.