


INCLUDES:

- 1x Toe Kick Vacuum unit
- 1x USB-C Cable



INSTRUCTIONS FOR USE

1. Remove all parts from the packaging
2. Charge the unit by plugging the USB-C Cable into the charging port on the front panel (Figure A). The light labeled "CHARGE" will turn on during charging and turn off when charging is complete. Charging time may take approximately 4-5 hours.
3. Place unit on the floor against a wall so that the front panel (Figure A) is facing the room.
 - If placing the unit in the toe kick space under a cabinet (recommended), press the square buttons on the sides of the unit (Figure B) to release the spring locks that will help secure the unit in place.


4. Press the large button labeled "PRESS" on the front panel (Figure A) to turn the vacuum on. The light labeled "POWER" will turn on when the vacuum is in use. Sweep dust into the vacuum port at the bottom of the front panel, and press the large button labeled "PRESS" again to turn the vacuum off.

- Note: Vacuum not suitable for large debris. Recommended to charge unit after each use.


5. To empty the dust compartment, turn the unit around and locate the rectangular cutout in the rear panel of the dust compartment (Figure B). Reach behind the lip of the cutout and pull away from the unit to remove the dust compartment. Pour out any dust or debris and reinsert the dust compartment.*

- If the spring locks were raised to secure the unit underneath a cabinet during installation, push down on the sliding knobs on the sides of the unit (Figure B) until they come to a stop and lock into place. This will lower the spring locks so that the unit can be removed.


Figure B



FILTER CLEANING INSTRUCTIONS



1. Pull upwards on the side panel that contains the filter to slide it free of the dust compartment.



2. Pull the filter free of the panel and shake any dust and debris loose over a trash can to clean. For more thorough cleaning, gently brush the filters and front mesh clean with a small brush or swab.
3. Reinsert the filter into the panel and slide the panel back into the slot in the dust compartment when cleaning is done.

LIMITED ONE YEAR WARRANTY

This product has a one year limited warranty on all materials and workmanship. TÉKO® warrants the original purchaser of this product that the product will be free from manufacturing defects in workmanship and material for a period of one (1) year from the date of original purchase. If within one (1) year this product fails due to defect in material or workmanship, TÉKO® will repair, replace or supply any defective part at their discretion. The purchaser must contact TÉKO® and provide a description of the defective part, including digital pictures if requested, with this original purchase documentation as validation of warranty coverage. This warranty does not cover or apply to: (a) damage to the product due to misuse, mishandling, and abuse, (b) products not used in accordance with instructions, (c) product not assembled or installed according to instructions, and (d) normal wear and tear.

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. YRDLLC shall not be liable for any incidental or consequential damages or any implied warranty of this product. Some states do not allow the exclusion of limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

IMPORTANT BATTERY SAFETY INFORMATION

WARNING: When using electric devices, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

1. This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. YRD#: HI2200 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
2. Rechargeable Lithium Ion batteries are potentially hazardous and can present a serious FIRE HAZARD if damaged, defective or improperly used. Failure to read and follow Li-ion safety instructions and warnings may result in personal injury, fire, and property damages if the battery is charged and/or used improperly. DO NOT SHORT CIRCUIT. Short circuits may cause fire and injury.
3. If liquid leaks from the battery cell, discontinue use immediately and properly dispose of the battery.
4. Do not charge battery in rain or in wet locations.
5. Use only the included battery.
6. Battery Type is: 2 Cell Li-ion Battery 7.4V 2000mAh.
7. Do not attempt to disassemble, remodel or destroy the battery, as it may cause battery leakage, fire, or bursting; and could also create sulfuric acid spills from the battery resulting in possible burns to person and damage to the immediate environment.
8. Charge battery using the specified charger and under the charging conditions as specified. Charging the battery under any other conditions may cause the battery to overheat, emit hydrogen gas, leak, ignite or burst.
9. When charging the battery always do so in a well ventilated area where you can observe the charging process.
10. Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.



Scan this QR code for the latest version of these instructions

Call for assistance at 1+ (619) 449-2392 or you can email us at: customercare@tekoclean.com or mail us at 9545 Pathway Street, Santee, CA 92071

Our Customer Care Department is available: Monday - Friday 8:30am to 4:00pm PST / 11:30am - 7:00pm EST
Santee, California 92071 | Patents Pending | Email: customercare@tekoclean.com | On the web: tekoclean.com |

Facebook & Pinterest: [tekoclean](https://www.facebook.com/tekoclean) | Instagram: [@tekoclean](https://www.instagram.com/tekoclean) Twitter: [@yrdllc](https://twitter.com/yrdllc)

January 2025 © Yeiser Research & Development LLC and TÉKO® Clean. Trade names, product names and logos used in this document are the trademarks or registered trademarks of Yeiser Research & Development LLC, Santee, CA 92071. WORLD WIDE PATENTS PENDING

© Yeiser Research & Development LLC and TÉKO® Clean; 2025. All rights reserved.

Made in China | Designed in the USA

John 3:16