



Activate your product warranty

Scan the QR code and
register your product
within 7 days to activate
your warranty



Registering also gives you access
to tips, exciting offers and more!

Relaxation LightScape Fountain INSTRUCTION MANUAL AND WARRANTY INFORMATION

WFL-101, WFL-102, WFL-103 | L-05928, Rev. 1

IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL APPLIANCE, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ AND SAVE THESE INSTRUCTIONS

DANGER – TO REDUCE THE RISK OF ELECTRIC SHOCK:

- Always place fountain on a firm, flat surface. A waterproof mat or pad is recommended for use under the fountain.
- NEVER place the fountain on a rug or carpet, or on a finished floor or wood furniture that may be damaged by exposure to water or moisture.
- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- DO NOT connect to any voltage other than that shown on the pump.
- DO NOT pump flammable liquids.
- DO NOT use water above 86° F.

WARNING – TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:


- Use this unit only for its intended use as described in this manual.
- DO NOT use attachments not recommended by Homedics; specifically, any attachments not provided with this unit.
- DO NOT operate outdoors or expose to water or weather. Indoor use only.
- Always keep the cord away from high temperature and fire.
- Close supervision is required when used by or near children, the elderly, or individuals with disabilities.
- Use only distilled water, and ensure the pump is fully submerged before turning on the device.
- DO NOT run the pump without water, as it may cause permanent damage. Avoid touching the water with bare hands while the unit is operating.
- Discontinue use immediately if the pump, cord, or adapter becomes damaged.
- Never operate this appliance if it has a damaged cord, plug, pump, cable or housing. If it is not working properly, if it has been dropped or damaged, return it to Homedics Consumer Relations for examination and repair.
- Contact the vendor for replacement parts.
- Never drop or insert any object into any opening.

- Operate only with the USB charging cord provided with the unit. Use a USB AC adapter that is suitable to provide the required input voltage and minimum input current (5VDC, 320mA). Use of any other cord or incompatible USB AC adapter may damage the product and may increase risk of harm to user or property.
- Fountain should be operated by ITE, Class 2, or equivalent power sources.
- DO NOT store or operate in temperatures greater than 140°F (60°C).

CAUTION – PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.

- The pump must be completely submerged in water. If the pump is making noises, most likely it is not completely submerged in water.
- Only set the fountain and fountain parts on waterproof surfaces.
- Keep cord away from heated surfaces.
- Do not carry this appliance by power cord or use the cord as handle.
- Never leave the appliance unattended, especially if children are present.
- To get the best flowing effect, product must be placed on a flat surface and should never be placed on an electrical appliance.
- Never let pump run dry, as this will shorten life of the pump.
- Never cover the appliance when it is in operation.
- Do not lift, carry, hang, or pull the pump by the power cord.
- Operate with tap or distilled water.
- Operate pump completely submerged for proper cooling.
- The electrical cord of this product cannot be replaced. If it sustains damage, you must stop using this product immediately and return it to the Homedics Service Center for repair. (See the warranty section for Homedics address.)
- Disconnect the appliance from outlet before putting hands into water.

GET TO KNOW YOUR FOUNTAIN



HOW TO USE

CAUTION: Before filling the reservoir with water, ensure the fountain switch is turned to the OFF position and unplugged.

CAUTION: Never add essential oils or other additives to the water reservoir.

NOTE: Always use 2 hands to carry the water tank. The convenient top-fill tank can be filled with a pitcher or at the faucet. For best results, use distilled water.

1. Unpack the product and all accessories from the package carefully. Keep packaging material for safe storage.
2. Place the product body on a flat, stable surface close to a power source.
3. Lift the cover with the pump attached. **DO NOT** remove the pump from the cover.
4. Fill the water reservoir to the MAX fill line with clean, room temperature water. **DO NOT** overfill the unit.
5. Replace the cover, ensuring the cover is properly seated over the fountain base.
6. Plug the USB cable into 5VDC USB wall plug, wall plug adapter, computer, or power bank.
7. Flip the switch to the on position.

3




4



5



6



Do not leave fountain unattended for extended periods of time - ensure water level is at max so pump does not run dry.

USAGE TIPS

- The pump **MUST** be submerged during use. Ensure water level is **ALWAYS** between the MAX and MIN fill lines to prevent damage to the pump. Add water to maintain proper water level throughout use. Using this fountain without sufficient water can damage the pump and void the warranty
- Use distilled water regularly to reduce mineral buildup and prevent pump clogging.
- Replace water every week to minimize microbial growth and odor.

HOW TO CLEAN AND CARE

CAUTION: Before cleaning, turn off and unplug the fountain.

DO NOT place any fountain components in the dishwasher.

DO NOT use abrasive pads or brushes, harsh chemicals, detergents, or liquid soaps to clean the fountain. Clean with a soft cloth or soft brush.


WEEKLY CLEANING

1. Remove the cover and pour out water from the reservoir.
2. Rinse the pump, cover, and reservoir with room temperature water. **DO NOT** wet the USB-A connector at the end of the USB cord.
3. Use a small soft brush or soft cloth to remove any debris.
4. Thoroughly dry all parts with a soft cloth and reassemble.

SCALE REMOVAL

Perform before storage or as needed. Prepare 1 cup (235 mL) of a cleaning solution using a 50/50 mix of white vinegar and water.

1. Remove the cover and pour out water from the reservoir.
2. Fill the reservoir with the cleaning solution.
3. Replace the cover with pump attached to the base. Swish the solution around the reservoir. DO NOT pour out the solution.
4. Let sit for 15 to 20 minutes
5. Pour out the solution from the water tank and reservoir.
6. Rinse the pump, cover, and reservoir with room temperature water. DO NOT wet the USB-A connector at the end of the USB cord. Use a small soft brush or soft cloth to remove any debris.
7. Thoroughly dry all parts with a soft cloth and reassemble.



STORAGE

Descale the fountain following the SCALE REMOVAL instructions. Store in a cool, dry location.

PROBLEM	SOLUTION
No power	<ul style="list-style-type: none"> ● Plug the unit in ● Flip the power switch to the on position ● Check circuits and fuses or try another outlet
Pump gurgles, spews, or “burps”	<ul style="list-style-type: none"> ● Fill the water reservoir to the MAX fill line ● Clean the fountain following the weekly cleaning instructions ● Clean the fountain following the scale removal instructions
Water overflows from fountain	<ul style="list-style-type: none"> ● Place the fountain on a firm, flat surface ● Ensure water levels are correct ● Ensure the fountain USB-A cord is plugged into a 5VDC USB port ● Check the reservoir for cracks or damage
No water is being pumped	<ul style="list-style-type: none"> ● Fill the water reservoir to the MAX fill line ● Clean the fountain following the weekly cleaning instructions ● Clean the fountain following the scale removal instructions
Peculiar odor	<ul style="list-style-type: none"> ● Clean the fountain following the scale removal instructions



1-YEAR LIMITED WARRANTY

Homedics sells its products with the intent that they are free of defects in manufacture and workmanship for a period of 1 year from the date of original purchase, or the date of delivery, whichever is later, except as noted below. Homedics warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

IMPORTANT: To ensure the most efficient processing of your warranty claim and to stay informed about product updates and new offerings, please register your product at www.Homedics.com/product-registration. Registration is quick, easy, and offers benefits such as faster warranty service, product update notifications, and special promotional offers.

Purchase must have been made from an Authorized Retailer (or their web site) or an Authorized Reseller. Authorized Resellers are Amazon.com, Walmart.com and ebay.com, but only if they say "Shipped and/or Sold by Homedics." **PRODUCTS PURCHASED FROM ANY OTHER ONLINE SELLERS WILL VOID THE WARRANTY.** A copy of a sales or gift receipt is required for all warranty claims. This warranty is valid only for the original purchaser or gift recipient from the date of original purchase, or the date of delivery, whichever is later, and is not transferable.

To obtain warranty service on your Homedics product, contact a Consumer Relations representative by email at cservice@Homedics.com or by phone at 1-800-466-3342 (USA) or 1-888-225-7378 (Canada). Please have the product model number available and be prepared to describe the nature of the problem. Our Consumer Relations representatives are available Monday-Friday 8:30am-7:00pm ET (USA) or 8:30am-5:00pm ET (Canada). Do not send any products to Homedics without contacting us first and obtaining a Return Authorization number. Homedics will, at its sole discretion, repair, replace, or provide a credit for any product that proves to be defective in materials or workmanship during the warranty period. If a replacement product is provided, it will be of equal or greater value and functionality. Replacement may be with a new or refurbished product or components. If the product is no longer available, a product of equal or greater value may be substituted. Any product or part that is replaced becomes the property of Homedics. The warranty period for any replacement product continues from the purchase or delivery date of the original product, not from the date of replacement.

This warranty does not cover: Products purchased from unauthorized retailers, resellers or distributors; damage caused by misuse, abuse, negligence, accidents, or improper maintenance; use for purposes other than those for which the product was designed or intended; damage resulting from improper or unreasonable use or maintenance; failure to follow operating instructions provided with the product; damage resulting from unauthorized repairs, alterations, or modifications; cosmetic damage including, but not limited to, scratches, dents, and broken plastic on ports, unless resulting from defects in materials or workmanship; damage caused by normal wear and tear, including but not limited to, the natural breakdown of colors and materials over extended time and use; damage from external causes such as fire, flooding, earthquakes, or other acts of nature; damage from power surges, power failures, or improper electrical supply; damage to any accessories used in conjunction with a covered product; products with removed, defaced, or otherwise illegible serial numbers or date codes; products sold "AS IS", as "refurbished", or as "reconditioned"; freight, shipping, or transportation costs for returning the product; loss of use or any other incidental, consequential, or indirect damages. Any software included with the product is provided "AS IS" unless expressly provided for in any enclosed software limited warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. HOMEDICS SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY. NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, HOMEDICS RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS OR PROVIDE A WEB COUPON FOR HOMEDICS' WEBSITE IN LIEU OF REPAIR OR REPLACEMENT. TO THE EXTENT PERMITTED BY APPLICABLE LAW, HOMEDICS' LIABILITY SHALL NOT BE GREATER THAN THE PURCHASE VALUE OF THE PRODUCT.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or country to country. Some states or countries do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so these limitations may not apply to you. For consumers who are covered by consumer protection laws or regulations in their country of purchase or residence, the benefits conferred by this warranty are in addition to all rights and remedies conveyed by such consumer protection laws and regulations. This warranty does not exclude, limit or suspend any rights of consumers arising from non-conformity with a sales contract.

Homedics does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate Homedics in any way beyond the terms set forth herein. This warranty

does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of Homedics.

For warranty claims, Homedics will cover the cost of shipping the replacement product for valid claims within the USA. Consumers are responsible for the cost of shipping the product to Homedics.

If you have a dispute, we hope to resolve it as quickly and easily as possible. First discuss your dispute with a Consumer Relations representative. If the Consumer Relations representative is unable to resolve your dispute, you agree that either Homedics or you can initiate arbitration as described in this section (the "Arbitration Agreement"). Arbitration means an impartial third party will hear the dispute between Homedics and you and provide a decision. Binding arbitration means the decision of the arbitrator is final and enforceable. A dispute is any unresolved disagreement between Homedics and you. A dispute also includes a disagreement about this Arbitration Agreement's meaning, application, or enforcement. The arbitrator shall decide any dispute under this Arbitration Agreement. Homedics and you each agree to waive the right to a jury trial or a trial in front of a judge in a public court. This Arbitration Agreement has only one exception regarding the disputes that are arbitrable: Either Homedics or you may still take any dispute to small claims court. This Arbitration Agreement is governed by the Federal Arbitration Act. The American Arbitration Association (AAA) will administer each arbitration and the selection of arbitrations will be according to applicable AAA rules. The arbitration will be held in the state of your residence. Neither Homedics nor you will be entitled to join or consolidate disputes by or against others as a representative or member of a class, to obtain relief in any arbitration in the interests of the general public, or to act as a private attorney general (the "Class Action Waiver"). Homedics will cover the cost of arbitration for any non-frivolous claims, but not the claimant's attorney fees. If any provision related to this arbitration agreement is found to be illegal or unenforceable, then such provision shall be severed from the arbitration agreement, but the rest of the agreement shall remain enforceable and in full effect. Homedics or you each can exercise any lawful rights or use other available remedies to: Preserve or obtain possession of property; exercise self-help remedies including setoff rights; or obtain injunctive relief (including public injunctive relief), attachment, garnishment, or appointment of a receiver by a court of competent jurisdiction. The substance of any disputes where public injunctive relief is available shall be decided by the arbitrator. Only if the claimant succeeds on its claim permitting the remedy of a public injunction may such claimant request that a court of competent jurisdiction enter an injunction in conformity with the arbitral award. You have the right to opt out of this Arbitration Agreement. If you opt out, neither you nor Homedics can require the other to participate in an arbitration proceeding. To opt out, you must contact Homedics by email at the address specified below no later than 30 calendar days from the date of the first consumer purchaser's purchase of the product. You must provide: (a) your name and address; (b) the date on which the product was purchased; (c) the product model number; and (d) the serial number found on the product. Opting out of the Arbitration Agreement shall not be construed as a modification of any other terms, including the Class Action Waiver.

For more information regarding our product line in the USA, please visit: www.Homedics.com. For Canada, please visit: www.Homedics.ca.

FOR SERVICE IN THE USA
CSERVICE@HOMEDICS.COM
8:30AM-7:00PM ET MONDAY-FRIDAY
1-800-466-3342

FOR SERVICE IN CANADA
CSERVICE@HOMEDICS.CA
8:30AM-5:00PM ET MONDAY-FRIDAY
1-888-225-7378

©2025 Homedics, LLC. All rights reserved.
Homedics is a registered trademark of Homedics, LLC.
Distributed by Homedics, LLC, 3000 N Pontiac Trail, Commerce Township, MI 48390
IB-WVFL-100