





## SEASONAL FOLDING CART WITH WHEELS


### FEATURES

- Storage crate with wheels, lid and handle is the perfect storage dolly for carrying items to and from school, the office, or the grocery store.
- Crate with lid can be used to store extra gear or also can be used as a seat.
- Handle extends and locks in place, then retracts for easy storage.
- The maximum weight capacity for the crate is 100 lbs. with or without the lid in place.




## ASSEMBLY

1.




Remove lid from the side of folded cart by pulling firmly.

2.




Open 2 latches, one on each side of folding cart.

3.





Pull open walls of cart.

4.




Push bottom floor of cart down.

5.



Slide the lock located at the top of both folding side walls into the LOCK position.


6.



Place lid on top of cart and snap lightly into place by pressing down on all 4 corners.

This is optional and not required to use.


7.



Push button on top of handle and pull up firmly to extend the handle.


## DISASSEMBLY

1.




Remove lid.


2.



Slide the lock located at the top of both folding side walls into the UNLOCK position.




3.




Pull bottom up.

4.




Collapse sides of cart.

5.



Close and lock latches, one on each side of folding cart.

6.



Snap lid on to outside of cart.



Use your camera on your phone to scan this QR code to view a short video on how to open and close.

**Something wrong? Don't worry!**  
**Contact us first and give us a chance to make it right!**

**If you are missing parts, received a damaged product, or need assistance with "how to use", we are here to help! Call us at 866.757.2333 or email us at [customer@henninglee.com](mailto:customer@henninglee.com). M-F (9am - 5pm CT)**