



# Welcome to the HearSound™ Family!

We're thrilled you've chosen the HearSound Soundball to enhance your TV listening experience. To make setup as simple as possible, we've highlighted the most important steps to help you get started quickly and enjoy your Soundball to the fullest.

Thank You for Your  
QVC Purchase!

## Quick Tips for a Great Start

### Step 1: Fully Charge Your Soundball

Charge your Soundball for at least **8 hours** before first use. This ensures your Soundball performs at its best right from the start.

### Step 2: Connect the Audio Cable from Your TV to the Transmitter

Your system includes two audio cable options, but you only need to use one.

**Optical Audio Cable:** Recommended for the best sound quality.

-OR- Remove the plastic caps from both ends of the digital optical audio cord before using.

**3.5mm Line-In Cable:** An alternative audio connection option if needed.

### Step 3: Power Your Devices

Your system includes two USB power adapters:

1. Use one adapter to charge your Soundball.
2. Use the second adapter to power the transmitter. However, if your TV has a USB port (common in TVs manufactured within the last 10 years), connect the transmitter directly to your TV's USB port using the included USB-C to USB-A cable. In this case, the second adapter can be saved for future use or to power an additional Soundball.

### Step 4: Pair Your Soundball and Transmitter

#### 1. Turn on both the Soundball and the transmitter.

A blue light on each will indicate they are powered on. It's okay if the light blinks.

#### 2. Check the Source on the transmitter.

Look for the blue light over the connection type you're using (**AUX, COAXIAL, or OPTICAL**) on the front of the transmitter. If it's not correct, press the **Source**  button to switch to the correct input.

#### 3. Pairing Steps (Follow these steps in sequence):

1. **Press and hold** the **Pair**  button on the transmitter until the blue light starts blinking.
2. **Release** the **Pair**  button immediately.
3. Then immediately **press and hold** the **Tone**  button on the Soundball.
4. **Release** the **Tone**  button as soon as you hear a beep from the Soundball.

Both blue lights should blink, then turn solid within 4–5 seconds, indicating they are paired successfully.



Thank you for choosing HearSound!