



## Quick Start Guide

Flip & Cook Air Fryer,  
Grill, & Dehydrator - 5.8Qt.



Model: AF2154

Place the appliance on a flat, heat-resistant surface with at least 6 inches of space around it. Ensure it's away from walls and other objects and plug into appropriate outlet.

Remove all packing materials. Wash the basket, rack, and grill plate in warm, soapy water. Wipe the outside of the main unit with a damp cloth.

### **Using the Air Fryer Function:**

1. Insert the basket and ensure the rack is in place.
2. Place food on the rack, ensuring it's not overfilled.
3. Slide the basket into the main body, then press the Start/Stop button.
4. Select the desired preset or manually adjust temperature and time. Press Start/Stop to begin cooking.

**Shaking or Turning Food:** For even cooking, shake or turn the food halfway through by removing the basket. The air fryer will resume once the basket is reinserted.

### **Using the Grill Function:**

1. Place the grill plate on the main body.
2. Adjust the temperature using the increase/decrease buttons.
3. Press Start/Stop to begin heating. Preheat for 2 minutes before placing food on the grill.

### **Using the Dehydrator Function:**

1. Place food evenly on the basket rack.
2. Select the "Dehydrate" preset and adjust time and temperature as needed.
3. Press Start/Stop to begin the dehydration process.

### **IMPORTANT**

When cooking is done, the appliance will beep and automatically shut off. Use oven mitts to handle the hot basket or grill plate.

Always use oven mitts when handling hot parts and avoid covering the air inlets or outlets during operation.