

# POWER CHOPPER XL™

The Power Chopper is the simple, all-purpose chopper for all your chopping, slicing and dicing needs. Make your favorite salads, cheese platter, fresh salsa and dessert toppings in seconds. The Power Chopper's stainless steel inserts make chopping fast and easy. You can chop: fruit, vegetables, herbs, cheese, nuts, chocolate, and much more!

## Instructions:

1. Place food on a cutting board or countertop. Hold the Power Chopper in one hand and push down hard with other hand. For larger slices, one or two plunges will be enough. For a smaller dice, repeat until you get the desired size.
2. To chop small foods such as nuts or chocolate, place inside the base cap, and push down until you get the desired size.
3. For finer results, use continuous chopping.
4. To separate skin from onions or garlic, place a half or a quarter face down on the cutting board.

Cleaning: Separate parts before loading in dishwasher. Top rack only.



**WARNING: Extremely sharp blades. Use caution while handling. Keep out of reach of children.**