FAQ'S:

Q. How do the locks work?

A. To lock your chair in place, simply flip the lock from down (vertical to arm rest) to facing straight out from the chair (horizontal to arm rest). Please note, lock will not be exactly perpendicular to arm rest in the locked position. Please do not try and force the lever beyond its position.



UNLOCKED

LOCKED

Q. The locking mechanism does not hold the chair in place or cannot be moved to the locked position.

A. You may need to adjust the tension on the lock. In order to do so simply loosen or tighten by turning the screw on the inside of the locking lever.



Q. Is assembly required?

A. No. Your gravity free recliner is ready for use upon removal from box. To set up your chair, first make sure lock levers are in down position (loosen tension if necessary). Then grip back frame and front armrest and begin pulling/pushing them away from each other until legs are in extended position and chair is in upright position. Attach pillow tray table and magazine pouch and begin enjoying your recliner.

Q. How do I attach the cup tray?

A. With the chair in upright position, place the cup tray underneath right armrest holding the cup tray with both hands. Clip back side of cup tray to back leg and gently push down until front side clips into place.

Q. How do I remove cup tray?

A. Grip the front and back of the cup tray. Place thumb on back tray clip and gently pull front of cup tray up and out towards you.

Q. How do I recline?

A. From the upright position, grip the arm rests and place your feet on the lower cross bar and begin pushing outward using your legs while slowly leaning back. When you reach your desired position, lock the recliner in place.

Q. How do I return to upright position?

A. Release the locking lever. Put your feet on the lower crossbar and exert a mild force downwards. At the same time, push the seat forwards by pulling armrests towards you.

Q. How do I fold my recliner for storage/transport?

A. Remove cup tray and magazine pouch. Make sure chair is in upright position and locking levers are in the unlocked (down) position. Make sure canopy is back and snapped into holders. Place cup tray and magazine pouch in seat of chair. Grip back of chair and arm rest and begin pulling towards each other. When together, place foot on leg of chair and push in. Your recliner is now ready for transport.

Q. What is the weight limit of my recliner?

A. Your recliner has been tested to support 360lbs. Do not exceed this limit.

Q. How do I care for my recliner?

A. Clean your recliner using a mild solution of soap and water. Rinse thoroughly and remove excess moisture with a dry towel. To prolong the longevity of your chair, store in a sheltered area when not in use.

Information provided by Barbara King