

## **Tips and Tricks for using the Dyson Corrale™ straightener for the first time**

- **First time use.** Gently slide instructions off of the machine before inserting the flight-ready tag. Slide the lock button up to open your Dyson Corrale™ straightener and insert the Flight-ready tag.
- **Charging dock.** Assemble the charging dock by putting the two pieces together and attaching the cable to the dock. Place Corrale on the dock to charge the machine.
- **Charge to 100%.** For best results, always start styling with 100% charge.
- **Set temperature:** Use the + or - button to select your desired styling temperature. You will hear another chime when Corrale reaches your desired temperature. Dyson recommends you start at a lower temperature than usual
- **Maximize run time with Charging dock:** Place your Dyson Corrale™ straightener in the dock when not in use and in between sections to extend run time. The OLED screen and chime will indicate that your machine is charging properly. Turn on the machine: Press and hold the power button until you hear a chime.
- **Flying with Corrale:** Before flying with Corrale, place the machine in flight ready mode by disconnecting the flight ready tab. This will disarm the battery.
- **Storing:** When on-the-go, place in heat-resistant travel pouch.
- **Key sounds:** Chimes to indicate your machine is heating up, chosen temperature reached, low battery, empty battery, charging, idle mode and service alerts. To turn off the prompt sounds, mute by holding the power and temperature buttons for five seconds.

### **Tips for smoothing:**

- Start with completely dry hair.
- Begin with Medium Heat (365 degrees) and adjust up or down depending on your hair type and texture.
- Select 1-2 inch sections of hair (depending on hair density) for best performance.
- Smooth hair in a single, fluid motion from roots to ends.
- Create additional details such as beveled ends by rotating 45-90 degrees inward or outward as you smooth ends of hair.
- To help get closer to the root, take sections at an angle.
- For finer hairline areas, reduce temperature.
- Finish with your favorite styling products.

### **Tips for curls and waves:**

- Start with completely dry hair.
- Begin with Medium Heat (365 degrees) and adjust up or down depending on your hair type and texture.
- Select 1-1.5 inch sections of hair (depending on hair density) for best performance.
- Clamp the section of hair and rotate the iron 1 full turn (for curls) or half turn (for softer waves) in the direction you want to curl.
- Immediately begin sliding the iron to the ends of the section.
- Finish with your favorite styling products.