



cook's essentials®

AIR FRYER

Quick Start Guide*

* See Owner's Manual for complete instructions and important safety information before using this product.

STEP 1



Remove Outer Basket
Pull **Basket Handle** straight out.

STEP 2



Load Fry Basket
Arrange the food you are cooking inside the non-stick **Fry Basket**.

STEP 3



Return Basket to Unit
Do not press the **Basket Release Button** or it will separate from the **Fry Basket**.

STEP 4



Select a Preset or Set the Temperature and Time
Follow instructions specific to your recipe. See recipes included.

STEP 5



Separating Fry Basket from Outer Basket
Remove **Outer Basket** from **Unit**. Set on a secure, heat-resistant surface. Move **Sliding Button Guard** and press **Basket Release Button** gently. Fry Basket will lift up & out.

IMPORTANT SAFEGUARD:

When cooking, place your **Air Fryer** on a stable, level, horizontal, and heat-resistant surface, away from any other appliances or combustible materials.

Never use your Air Fryer on a stove top of any kind. When in use, do not place this appliance against a wall or on or against other appliances. Leave at least 5" free space on the back and sides and above this appliance. Do not place anything on top of the Air Fryer.

NOTE:

- Before plugging the Air Fryer into a power outlet, make sure all packaging material is removed from both outside and inside the Unit.
- Wash all components before first use.
- After the cooking cycle has ended, the White Fan Icon will continue to flash while the Unit cools down. After 20 seconds, the Unit will power OFF automatically.

NOTE: Some foods require 'Shaking' to ensure even cooking. Remove **Outer Basket & Fry Basket** from **Unit**, gently shake contents, and place back in **Unit** to continue cooking. (Unit will auto shut off for safety and turn back on once **Basket** is back in place)

CAUTION: The Outer Basket and Fry Basket will become hot... wear dry oven mitts when handling.