

MagniFlex FAQ's

Q. Is the MagniFlex good for coins?

A. Yes! it is good for coins as well as any other small inscriptions on metals.

Q. How much does the MagniFlex magnify text?

A. Depending on the viewing angle and expansion of the silicone, the MagniFlex can achieve a 2-4x magnification. For the largest magnification, fully extend the silicone (4x Magnification).

Q. Can I look through the magnifier at an angle?

A. Yes, you can tilt the magnifying glass for a more comfortable viewing experience and achieve a 3x magnification.

Q. Can I change the brightness of the MagniFlex LED Light?

A. Yes, there are 3 brightness modes on the MagniFlex.

Q. What are the different light modes?

A. The LED Light on the MagniFlex The LED Lights have three adjustable brightness levels. Single click the LED Light Power Button to turn the LED Light on and scan through the modes.

Light Modes: High | Medium | Low | Off

Q. What is the included Type-C Cable for?

A. The LED Light on the MagniFlex can be powered by the coin batteries, or by plugging in the Type-C Cable to the Type-C Input and a USB power source (power source not included).

Q. How do I change the batteries of the MagniFlex?

A.

1. Open the Coin Battery Door by pushing outwards against the arrow with light pressure and lifting upwards.
2. Install (2) of the CR2016 Coin Batteries in the Coin Battery Slot with the writing on the Coin facing upwards.

NOTE: The LED Light will not work if the CR2016 Coin Batteries are installed incorrectly.

Q. Is the MagniFlex rechargeable?

A. No, the MagniFlex is not rechargeable. You can simply replace the CR2016 coin batteries or use the included Type-C Cable to power the LED Light.

Q. Can I travel on an airplane with the MagniFlex?

A. Yes, you can carry the MagniFlex on an airplane.

Q. Is there a warranty?

A. Every MagniFlex comes with a 1-Year Limited Warranty.

Q. Who do I contact if I have a question or issue with the MagniFlex?

A. For any inquiries regarding the Lumenology Portable Motion Light, please contact our support team at LimitlessInnovations.com/Support, email us at Support@LimitlessInnovations.com, or call us at (855) 843-4828