

CHARGING

The USB-enabled pLink charger allows the device to be rechargeable using either a traditional wall mount AC adaptor or USB port on a computer. A wall mount AC adaptor and USB plug are included. A fully charged device averages 27-128 minutes of use depending on the type of brush head used and speed at which it is run.

The convenient pLink charger magnetically attaches to the device handle as shown. The pLink charger can be attached to the device with or without the drying stand.

CHARGING INDICATORS

Action	Indicator
Attach pLink charger	Handle emits two pulses.
Charge the handle	The battery life indicator will flash from red to green as it charges.
When fully charged	The battery life indicator will illuminate solid green. Allow 24 hours for a full charge.

NOTE: Using the Turbo function may deplete the battery of the device faster.



The pLink charger is compatible with 100-240 Volts AC; 50/60Hz, allowing it to be used worldwide with the appropriate country adapter. If the shape of the plug does not fit the power outlet, use an attachment plug adapter of the proper configuration for the power outlet.

NOTE: The Smart Profile handle is not compatible with chargers for the Clarisonic PRO, PLUS, Mia 2 or Mia 1 model.

BATTERY LIFE

This device has a battery life indicator located just below the smart brush head indicator. During and at the end of a cleansing cycle the light will appear green or red depending on the amount of battery life available on the device.

Indicator	Battery Life Level
Solid Green	Full
Flashing Green	High
Flashing Red	Low
Flashing Red, Beeps + Pulses	Empty

To check the battery life on your handle, press the Turbo button **while the charger is attached** to the handle.

Percentage of Battery Life	Indicator
75 – 100%	Numbers 1, 2, 3 & 4 illuminate
50 – 74%	Numbers 1, 2 & 3 illuminate
25 – 49%	Numbers 1 & 2 illuminate
5 – 24%	Number 1 illuminates
Less than 5%	None

