

## **Calista Body Waver Heated Styling Tool FAQ's & Styling Tips**

### **FAQs:**

Q: How big are the barrels on the Large BodyWaver?

A: The barrels are both 1.25".

Q: How big are the barrels on the Small BodyWaver?

A: The barrels are both 1".

Q: How long does my hair have to be to use the Small BodyWaver?

A: We recommend the Small BodyWaver for hair that is shoulder length and shorter.

Q: How long does my hair have to be to use the Large BodyWaver?

A: We recommend the Large BodyWaver for hair that is below the shoulders.

Q: Do I use the BodyWaver on wet hair or dry hair?

A: The BodyWaver is meant to be used on dry hair only.

Q: How long does the BodyWaver take to heat up?

A: About 1 minute.

Q: What are the styling times?

A: 4 seconds, 6 seconds, and 8 seconds

Q: What are the temperature settings?

A: 320° F, 360° F, and 400° F

Q: How do I know which styling time to use?

A: We recommend 4 seconds for a loose wave, 6 seconds for a classic, natural-looking wave, and 8 seconds for a strong, defined wave.

Q: How do I know which heat setting to use?

A: We recommend fine, chemically-treated hair style at 320°F, regular, non-resistant hair style at 360°F, and coarse, resistant hair style at 400°F.

Q: How do I know when to move onto the next section?

A: The tool will beep once you have reached 4, 6 or 8 seconds.

Q: Is the BodyWaver dual voltage?

A: Yes, the BodyWaver is dual voltage up to 240 V. All you will need to use is a plug adapter; you do not need to use a converter, using one will damage the tool.

Q: How long is the cord?

A: The BodyWaver has a 7' Swivel Cord.

Q: What are the plates made out of?

A: The plates are ceramic coated and feature our fusion technology for less frizz and more shine.

Q: Does the BodyWaver have an automatic shut off?

A: Yes, the BodyWaver has a 1-hour auto shut off.

Q: How do I keep the plates closed when I'm not using the tool?

A: There is a locking mechanism at the base of the tool. Simply turn the ring at the base of the tool to unlock the plates when you are ready to use the tool. When you are finished styling and the tool is unplugged and completely cooled, close the plates and turn the ring at the base to lock the plates.

### **Tips & Tricks**

- For natural-looking beachy waves, style 1" wide sections of hair at a time.
- For classic, uniform waves, style 2" wide sections of hair at a time.
- If you want a consistently perfect wave pattern, line up the BodyWaver with your outermost wave and slowly work the tool down your next section of hair. This will give you those uniform waves that look like a professional did them!