

ASSEMBLY AND CARE INSTRUCTIONS

IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY


10244-TQ (Turquoise) 10244-CO (Copper) 10244-GM (Gunmetal) 10244-SS (Stainless Steel)

Made in China

10244-BR (Bronze) 10244-RD (Red)


📞 **1-800-711-1585** Monday thru Friday 9:00 AM to 5:00 PM (PST) (English, French and Spanish available)

Features:



Choosing the right location:

A few important things to remember prior to installation. Your solar lights should be installed in an area that gets DIRECT SUNLIGHT. Your solar lights will produce more hours of operation when installed in an area which is free from cover, shade, or shadowing.



Assembly

Attaching the Post to the Ground Stake


- □ Remove inverted Ground Stake stored inside the Post.
- ☐ Attach the Post (C) to the Ground Stake (D) by pushing the Post (C) onto the top of the Ground Stake (D).
- □ Push the Post-Stake assembly into the ground.



NOTE: Do not use a hammer. If the ground is hard, use water to soften.




CAUTION: The Ground Stake is sharp. Be careful when handling to avoid injury.



Removing the battery pull tab and Switching Colors


- For first time use, remove pull tab from the battery compartment, located under the solar top housing (A). Note, this product does not have an ON/OFF switch.
- The Color Control Button allows you to manually cycle through the

colored LED options. To select the desired color, press the Color Control Button. The selected color will automatically stay the same color on subsequent cycle nights until manually changed to a different color.



Attaching the Solar Top Housing

- Attach the Solar Top Housing (A) on top of the Glass Lens (B) using a clockwise twisting motion.
- onto of the Post Stake (C & D).



□ Insert the Solar Top Housing and Glass (A & B)



Your Energizer® solar lights are ready for use!



How solar lights work

Solar lights have a solar cell that converts sunlight into electricity. This electricity is used to recharge the built-in battery each day. A built-in sensor automatically turns on the light at night. The more sunlight received during the day, the longer the light will operate that night. Since solar lights are powered entirely by sunlight they receive each day, operating times will vary by specific location, daily weather conditions, and season

For product or warrranty inquiries, please contact **1-800-711-1585** www.energizersolarlights.com Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Alpan Lighting Products, Inc. All other brand names are trademarks of their respective owners. Neither Alpan Lighting Products, Inc. nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.


Care & Cleaning

- Clean the solar panel with a damp cloth. Do not use any chemicals or abrasives.
- Keep the solar panel free of snow and debris to allow the battery to charge properly.

CAUTIONS: BATTERY INSTRUCTIONS

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of
- Clean the battery contacts and also those of the device prior to battery installation.
 Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove used batteries promptly.

For recycling and disposal of batteries to protect the environment, please check the internet or your local phone directory for local recycling centers and / or follow local government regulations.



Important: Use only AA 1.2V 600 mAh Nickel Metal Hydride (Ni-MH) rechargeable batteries.

Troubleshooting

| Problem | Solution |
|--|---|
| Light stops working after period of working properly. | The battery is not adequately charged. Place the unit in direct sunlight for three sunny days. The lights are located in a location that does not provide enough sunlight. If a tree, house, or other object is shading the solar light, move the light to a sunnier location. Also note that lighting time will always be shorter on overcast days. |
| | The light level is too high for the solar lights to turn on. The solar lights are designed to turn on when it is dark outside. Make sure the solar top housing is not under any direct light source when testing. The battery may be weak or can no longer produce a charge. Replace the battery. |
| The lights only operate for a short duration in the evening. | The lights are located in a location that does not provide enough sunlight. If a tree, house, or other object is shading the solar light, move the light to a sunnier location. Also note that lighting time will always be shorter on overcast days. The battery may be weak or can no longer produce a charge. Replace the battery. |

Manufacturer's One Year Limited Warranty

Manufacturer warrants this product to be free for one (1) year against any defects that are due to faulty materials or workmanship. Manufacturer shall promptly correct such defects by repair or replacement, at its option. This warranty covers only product defects and shall expire one year after the date of purchase by the original purchaser. Proof of Purchase (Sales Receipt) is required.

This warranty does not apply to (1) bulbs and batteries or (2) defects caused by and resulting from misuse, neglect, accident or improper operation, maintenance, storage, transportation, or handling of the product. The warranty does not cover any transportation costs for return of the product or for reshipment of any repaired or replaced product, or cost associated with installation, removal or reinstallation of the product. This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers. This warranty does not cover surface scratches or weathering as this is considered normal wear.

Manufacturer shall have no responsibility for damage to persons or property or other loss or injury resulting from a defect in the product or from improper use or installation. UNDER NO CIRCUMSTANCES SHALL MANUFACTURER BE LIABLE FOR SPECIAL OR CONSEQUENTIAL DAMAGES. ANY WARRANTIES IMPLIED BY LAW, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO ONE YEAR AFTER THE DATE OF THE ORIGINAL PURCHASE. In no event shall the Manufacturer's liability under this warranty exceed the cost of repair or replacing such defective product, and the Manufacturer's maximum liability under any warranty is in lieu of all other warranties expressed or implied.

Some states do not allow the exclusion or limitation of special or consequential damages or allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may have rights that vary from state to state. If you feel you have a claim under this warranty, contact consumer service for advice on handling the claim. Written notice of any defects must be given to Manufacturer upon discovery.